CROWN EASY CHAIR

Crown Easy Chair

Fabric Supplier

Specifications

Width: 690 mm

Depth: 660 mm

Weight: 16 kg

Height: 760 mm

Seat Height: 390 mm

Information

Designer: Chris Martin

Year: 2012



Product image may differ from your selection.

Description

The Crown collection comprises of an armchair (with or without a writing tablet) and an easy chair. These pieces are cleverly constructed, with a playful element to them. Backrests are perched on the armrests, seemingly unsupported but in fact relying on a strong, concealed steel joint.

Lead time 6 weeks.

Instructions

For cleaning of the fabric/leather, see instructions related to the specific fabric/leather in use.

Instructions for Fabric

Vacuum frequently, ideally every week, at half power where appropriate. Wipe upholstery fabrics made from polyurethane with a dry or moist cloth. May also be vacuum cleaned with a soft brush. For stain removal first, scrape off any liquids or hardened residues with a spoon or a scoop before you proceed. Any loose particles must be vacuum leaned before further cleaning. Liquids must be soaked up with an absorbent napkin or cloth. Remove non-greasy stains by carefully dabbing with a lintfree cloth or sponge wrung out in warm water. Edge marks can be avoided by dabbing gently in circular motions towards the centre of the stain with a clean lint-free cloth. Remove greasy stains by using
appropriate detergents or solvents. In all cases, we recommend to test stain-removal agents on an inconspicuous area first, to see if there is any effect on the cover. Make sure to dry the fabric fully before use. It may also be necessary to use a hairdryer to avoid leaving edge marks. This applies especially to microfibre textiles. These tips are purely recommendations and cannot guarantee complete stain removal. In all cases, we recommend contacting a professional dry cleaning. Warning – do not rub the material hard because this could result in loss of colour or potentially damage the nap. Be careful when using solvents; these could dissolve the upholstery materials beneath. Never use un-concentrated
detergents or bleach, ammonia or soap intended for hard surfaces. It is usually recommended that upholstered furniture
with normal commercial use should be cleaned 2–3 times a year. Upholsteries in private households usually need less frequent cleaning. For more information see our website.