JIG EASY CHAIR

Jig Easy Chair

Color	Black - RAL 9005
Fabric Supplier	



Specifications

Width: 630 mm

Depth: 630 mm

Weight: 9 kg

Height: 760 mm

Seat Height: 380 mm

Information

Year: 2012

Description

Jig is a lightweight, robust and stackable armchair for commercial spaces and hospitality areas. It's made from twelve simple steel tubes that are joined together in a fresh design for an old typology.

Lead time 24 weeks.

Instructions

For cleaning of metal surfaces: Rinse with large quantities of water. Clean with wetting agent solution and use a sponge or soft cloth. Post-rinsing and drying. Specific instructions based on type of soiling: Greasy film can be removed with a concentrated wetting agent solution, alcohol or surfactant, after allowing the solution some time to break down the film before removing. Unidentifiable, stubborn dirt can be treated with facade cleaner (e.g., Ambruch2 www. ambruch.de) or Power Wipes www.interflon. net. Note: Special care should be taken with coatings that have a metallic, pearl mica or matte effect. The specific methods listed here should be tested accordingly for possible damage to the surface. For cleaning of the fabric/leather, see instructions related to the specific fabric/leather in use.

Instructions for Fabric

Vacuum frequently, ideally every week, at half power where appropriate. Wipe upholstery fabrics made from polyurethane with a dry or moist cloth. May also be vacuum cleaned with a soft brush. For stain removal first, scrape off any liquids or hardened residues with a spoon or a scoop before you proceed. Any loose particles must be vacuum leaned before further cleaning. Liquids must be soaked up with an absorbent napkin or cloth. Remove non-greasy stains by carefully dabbing with a lintfree cloth or sponge wrung out in warm water. Edge marks can be avoided by dabbing gently in circular motions towards the centre of the stain with a clean lint-free cloth. Remove greasy stains by using appropriate detergents or solvents. In all cases, we recommend to test stain-removal agents on an inconspicuous area first, to see if there is any effect on the cover. Make sure to dry the fabric fully before use. It may also be necessary to use a hairdryer to avoid leaving edge marks. This applies especially to microfibre textiles. These tips are purely recommendations and cannot guarantee complete stain removal. In all cases, we recommend contacting a professional dry cleaning. Warning – do not rub the material hard because this could result in loss of colour or potentially damage the nap. Be careful when using solvents; these could dissolve the upholstery materials beneath. Never use un-concentrated detergents or bleach, ammonia or soap intended for hard surfaces. It is usually recommended that upholstered furniture with normal commercial use should be cleaned 2–3 times a year. Upholsteries in private households usually need less frequent cleaning. For more information see our website. Removing stains from textiles in the Divina family can be difficult, as the fabric is being pressed after fulling in order to achieve the felt-like surface. Particularly on new woollen covers, the fibres will slightly rise when the fabric becomes moist. The moist area will appear as a darker stain. The textile cannot be pressed again, however, it is possible to reduce the discoloration by spraying water over the entire furniture piece. When using the furniture and at normal humidity levels, the wool fibres will rise and potential stains will become less visible.